

RUA NOVA - SENHOR DO BONFIM, PENEDO/AL

Tabela de Volumes						
Estaca	Área de Aterro	Área de Corte	Volume de Aterro	Volume de Corte	Volume Acum. de Aterro	Volume Acum. de Corte
0+0.00	0.00	1.68	0.00	0.00	0.00	0.00
0+12.30	0.01	0.89	0.03	15.87	0.03	15.87
1+0.00	0.00	1.96	0.02	11.04	0.05	26.91
2+0.00	0.00	1.71	0.00	36.69	0.05	63.60
3+0.00	0.00	1.74	0.00	34.51	0.05	98.11
3+10.21	0.00	1.93	0.00	18.73	0.05	116.84
4+0.00	0.00	1.60	0.00	17.32	0.05	134.16
4+12.56	0.00	3.38	0.00	31.41	0.05	165.57
5+0.00	0.00	2.01	0.00	20.19	0.05	185.76
5+19.50	0.00	1.70	0.00	36.34	0.05	222.10
6+0.00	0.00	1.67	0.00	0.86	0.05	222.96
6+10.10	0.00	3.35	0.00	25.35	0.05	248.31
7+0.00	0.00	1.65	0.00	24.87	0.05	273.18
7+3.99	0.00	0.00	0.00	3.06	0.05	276.24
8+0.00	0.04	0.45	0.28	3.67	0.33	279.91
8+3.00	0.20	0.25	0.34	1.08	0.67	280.98
9+0.00	0.00	1.24	1.67	12.72	2.35	293.70
10+0.00	0.00	1.15	0.00	23.87	2.35	317.57
10+7.01	0.00	0.09	0.00	4.34	2.35	321.92